

#	ROOM / AREA	CALL TYPE	TIMER
1	Hold 2	Staff Emerg	00:09
2	Exam 2	Normal	01:04
3	Exam 7	Clean RM	00:42

SYSTEM MUTE ETH 10:53.22

CDT

The Call Display Terminal (CDT) was designed for hospital call centers, where it displays calls received from the West-Call® Endeavor and West-Call® Odyssey Plus systems until the call is cancelled. The CDT has radio paging capabilities as well. One or more call types may be assigned to any number of pagers and each call type may be assigned a color scheme and a call tone. Pressing the mute button will temporarily mute call tones, however if the mute function is active when a new call enters the system, the mute function will automatically deactivate and sound the appropriate tone.

- ▶ Displays calls until call is cancelled.
- ▶ Simple to operate.
- ▶ Call type may be assigned color and a call tone
- ▶ Use for central annunciation of code blue and fault alarms.

DESCRIPTION	MODEL NO.
Call Display Terminal	/CDT

- To combine features, specify corresponding code letters that begin with a (/) to the end of the model number (e.g., NCM-815T/TQI)

Processor	486 Based Microprocessor
Hard Drive	8 MB Solid State Disk
Memory	4 MB RAM
Video	Video printed wiring board supplying VGA video
Input Power	100-240 VAC, 60 Hz, .5A



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems Incorporated
 P.O. Box 640 • Danville, CA 94526 • 800-761-1180 • fax: 925-831-0842 • info@westcall.com