

**LDL2 / SDL2**

The West-Call® LDL2 provides the required visual signal to notify staff members of a room's status. The Dome Light is equipped with four sections; each section is capable of displaying a multitude of colors under program control. The standard colors offerings are yellow, green, amber, red, blue, violet and turquoise. LED lights will virtually never burn out, as compared with an incandescent bulb. The Corridor Dome Light mounts on the wall or ceiling, which offers increased visibility from any reasonable angle and supports a wide variety of signals. Typical applications include corridor indication of patient calls, patient waiting, staff calls, emergency, code blue and code pink indications. The LDL2 AND SDL2 are compatible with the West-Call® Novus® system only.

- ▶ Translucent wedge-shaped dome lens for maximum visibility in all directions, even at great distances and under high ambient lighting conditions
- ▶ Easy connection to West-Com “Special Orange” cable via RJ-5 (data) and 3-pin panduit (power).
- ▶ Oversized two-gang faceplate, hospital-grade ABS plastic
- ▶ Color is Pantone 1C Warm Grey
- ▶ Lens is made from unbreakable polystyrene UL94V0 plastic
- ▶ Normal and emergency calls distinguished by different visual signals for positive identification of call priority
- ▶ LED will virtually never burn out

DESCRIPTION	MODEL NO.
LED Corridor Dome Light for Novus® and Hybrid PAT-2000 audio patient stations	LDL2
LED Corridor Dome Light for Novus® devices without audio	SDL2

- For use with the West-Call® Novus® systems only

Operating Voltage	28VDC
Power Consumption	<2 watts
Size	5 1/4"H x 5 1/4"W x 3 3/4"D
Mounting	4 11/16" square back box with two-gang plaster ring. Raco 257 with 818 or equivalent
Faceplate	Hospital grade ABS plastic back plate with attractive finish. Pantone 1C Warm Grey
Termination	Mating connectors are RJ-45 and Panduit CE156F22-3 (3 each, included) (SDL2 requires one less CE156F22-3)
Luminary	Molded white Polystyrene plastic, replaceable
LED colors	Red, Green, Blue, Yellow, Amber, Violet, Turquoise- via program control



View West-Com's complete West-Call® line of healthcare communications solutions at [www.westcall.com](http://www.westcall.com)

West-Com Nurse Call Systems, Inc.  
 2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • [info@westcall.com](mailto:info@westcall.com)