



PUSH/PULL STATION

Because not every bathroom call is an emergency, the Push/Pull Station allows patients to place assistance calls from a bathroom by simply pressing one button...or to call for emergency help by pulling the cord.

- ▶ Large color-coded call type labels for placement of calls
- ▶ Highly visible call LED to assure that a call has been placed
- ▶ Large color-coded "CANCEL" label for cancellation of calls
- ▶ Solid state circuitry
- ▶ Fire retardant high-impact hospital grade molded thermoplastic with inlaid membrane
- ▶ Attractive Lexan membrane (Pantone 1C Warm Grey)
- ▶ Easy plug-in connection into the system wiring

All West-Call® push button devices have a CANCEL button and a call button. Below is a list of the type of push buttons available along with the color of the button and the wording on the button.

STATION TYPE	COLOR OF CALL BUTTON	NOVUS MODEL NO.	ODYSSEY	ENDEAVOR
Emergency Pull Cord and Push Button Station. Single Gang device.	YELLOW	EPCP-2000	EPCP-2000	EV2K-EPCP
Emergency Pull Cord and Push Button Station with a polyurethane cord to help with infection control. Single gang device.	YELLOW	EPCP-2000/P	EPCP-2000/P	EV2K-EPCP/P
Emergency Pull Cord and Push Button Station with a glow-in-the-dark polyurethane cord to help with infection control. Single gang device.	YELLOW	EPCP-200/P/G	EPCP-200/P/G	EV2K-EPCP/P/G
Emergency Pull Cord and Push Button Station with a water resistant gasket. Single gang device.	YELLOW	WPCP-2000	WPCP-2000	EV2K-EPCP WPCP
Emergency Pull Cord and Push Button Station with a water resistant gasket and a polyurethane cord to help with infection control. Single gang device.	YELLOW	WPCP-2000/P	WPCP-2000/P	EV2K-EPCP WPCP/P
Emergency Pull Cord and Push Button Station with a water resistant gasket and a glow in the dark polyurethane cord to help with infection control. Single gang device.	YELLOW	WPCP-2000/P/G	WPCP-2000/P/G	EV2K-EPCP WPCP/P/G

- Custom color faceplates available as an option upon request
- Custom wording and colors on membranes available upon request
- For use with the West-Call® Novus®, Odyssey Plus and West-Call® Endeavor systems

Operating Voltage	12-30 VDC; 12-18 VAC
Power Consumption	1 watt maximum
Dimensions	4 ½" H x 2 ¾" W x 1 ½" D
Mounting	4-inch square backbox with one-gang plaster ring, Raco 190 with 768 one-gang adapter or equivalent. Minimum 2 1/8" depth required. Normal mounting is vertical. For remodel areas, use Raco #500 or 503 with #977 Grip-Lok's or equivalent. Minimum 2 ½" depth required
Faceplate	Hospital grade UL94V-0 ABS molded thermoplastic with inlaid membrane
Faceplate Color	Standard color is Pantone 1C Warm Grey
Membrane	.010 Lexan with hardcoat finish background color Pantone 4C Warm Grey. Cancel color Pantone 1C and 11C Warm Grey
Lamp Life	500,000 hour minimum
Switch Life	100,000 cycles minimum
Cable Requirement	Use 4 conductor #22AWG cable to associated patient station, SDL-1000 or I/O board. Use 6 conductor #22AWG cable to associated Closure Plus Modules
Termination Requirement	Plug-on connector allows rapid mass termination. Mating connector is a Panduit CE156F22-10



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
 2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com