



**Nurse Aide
Locator**



**Yellow and Red
Level Locator**



**Green and Yellow
Level Locator**

The Locator station provides two levels of staff location, as well as other unique features such as: cancellation of calls and selective audio page functions. When used with the West-Call® Odyssey Plus or West-Call® Endeavor systems, locators can be a signaling device for any purpose.

Features

- ▶ Highly visible call LED to assure the call has been placed; 500,000 hour life expectancy
- ▶ Easily operated push color-coded area
- ▶ Fire retardant high impact molded thermoplastic
- ▶ Solid state circuitry
- ▶ Plug-in connectors for easy system connection/service
- ▶ Designed to work with all West-Call® nurse call systems
- ▶ Custom colors and text available

Ordering Information

DESCRIPTION	ODYSSEY PLUS MODEL NO.	ENDEAVOR MODEL NO.
Two Level Locator with a Green Level 1 Button and a Yellow Level 2 Button	LOC-1000	EV LOC
Two button locator with a Green Nurse Button and a Yellow Aide Button	LOC-1000/NA	EV LOC/NA
Two Level Locator with a Yellow Level 1 Button and a Red Level 2 Button	LOC-1001	EV LOC/1

- Custom colors and text available upon request
- For use with the West-Call® Odyssey Plus and West-Call® Endeavor systems

Technical Specification

Operating Voltage	12-30VDC
Power Consumption	1 watt maximum
Size	4 1/2"H x 2 3/4"W x 1 1/4"D
Mounting	4" square backbox with 1 gang plaster ring, Raco 190 with 768 or equivalent. 2 1/8" minimum depth required. Normal mounting is <u>Vertical</u>
Faceplate	Hospital grade ABS UL94V-0 molded thermoplastic with inlaid membrane
Faceplate Color	Warm Grey (Pantone 1C)
Membrane	.010 Lexan with hardcoat finish
Membrane Color	.010 Lexan with hardcoat finish background color Grey (Pantone 4C). Copy color Warm Grey (Pantone 1C and 11C)
Termination	Plug on connector allows rapid mass termination. Mating connector - Panduit CE156F22-10
Cable Requirements	6 conductor #22AWG cable to associated station or I/O board



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems Incorporated
 P.O. Box 640 • Danville, CA 94526 • 800-761-1180 • fax: 925-831-0842 • info@westcall.com