



CDL-1000 Series

The West-Call® Corridor Dome Light provides the required visual signal to notify staff members of a room's status. It can be used with the West-Call Odyssey Plus and Endeavor systems. The Dome Light can be equipped with up to four sections with one lamp per section, offering a wide variety of signals. High intensity five-watt incandescent lamps are easily visible from any reasonable angle. The Corridor Dome Light can be mounted on the wall or ceiling, and the lamps are available in various colors. Typical applications include corridor indication of patient calls, patient waiting, staff calls, emergency, code blue, and code pink indications, as well as zone light applications.

- ▶ Translucent wedge-shaped dome lens for maximum visibility in all directions, even at great distances and under high ambient lighting conditions
- ▶ Front-replaceable lamp(s) for simplified service
- ▶ Oversized two-gang faceplate, hospital-grade ABS plastic
- ▶ Normal and emergency calls distinguished by different visual signals for positive identification of call priority
- ▶ Lens is made from unbreakable polystyrene UL94V0 plastic
- ▶ Color is Pantone 1C Warm Grey

VERSIONS AND MODEL NUMBERS:

STATION TYPE	ODYSSEY	ENDEAVOR
Corridor Dome Light with one socket and one lamp (Color will be white unless ordered otherwise)	CDL-1001	CDL-1001
Corridor Dome Light with two sockets and two lamps (Colors will be white and green unless ordered otherwise)	CDL-1002	CDL-1002
Corridor Dome Light with three sockets and three lamps (Colors will be white, green and amber unless ordered otherwise)	CDL-1003	CDL-1003
Corridor Dome Light with four sockets and four lamps (Colors will be white, green, amber and red unless ordered otherwise)	CDL-1004	CDL-1004
Smart Dome Light with four sockets and four lamps (Colors will be white, green, amber and red unless otherwise specified). Used only for West-Call® Odyssey Plus	SDL-1000	
Auxiliary Zone Light with four sockets and four lamps (Colors will be white, green, amber and red unless otherwise specified). Used only for West-Call® Odyssey Plus	ZDL-1000	
Multiple Zone Light with four sockets and four lamps (Colors will be white, green, amber and red unless ordered otherwise). Used only for West-Call® Odyssey Plus	MZL-1000	
Corridor Dome Light with one socket, one lamp and a Closure Plus Module (Lamp color will be white unless otherwise specified). Used only for West-Call® Odyssey Plus	CDL-1001/CL	

- For use with West-Call® Odyssey Plus and Endeavor systems unless otherwise noted above

Operating Voltage	24VDC
Power Consumption	5 watts per lamp
Size	5 1/4"H x 5 1/4"W x 3 3/4"D
Mounting	4 11/16" square backbox with two-gang plaster ring. Raco 257 with 818 or equivalent
Faceplate	Hospital grade ABS plastic back plate with attractive finish. Pantone 1C Warm Grey
Termination	CDL-1001 through 1004 have 6" wired pigtails, SDL-1000, ZDL-1000 and MZL-8000 plug-on connectors allow rapid mass terminations. Mating connectors are Panduit CE100F22-7, 10,12
Luminary	Molded white Polystyrene plastic, replaceable
Lamp colors	White, Green, Amber, Red, and Blue. Note: Blue is not recommended due to poor visibility at distances of more than 10 feet, or where fluorescent lamps are within 10 feet
Certifications	UL-1069 for US and Canada, E139082

NOTE: This information should not be used for final design. Consult West-Com for total system requirements. Specifications subject to change without notice.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
 2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com