



Duty Station

The Duty station is an audible alert device commonly used in staff lounge areas where staff members can be alerted to system calls. It is capable of producing multiple tones to differentiate call types.

- ▶ Reports 3 levels (Odyssey Plus) and 7 levels (Endeavor) of calls with audible buzzer
- ▶ Plug-in connection to system wiring (Odyssey Plus Only)
- ▶ Fire retardant painted cold rolled steel
- ▶ Solid state circuitry (Odyssey Plus Only)
- ▶ Color is a warm grey (Pantone 1C)

VERSIONS AND MODEL NUMBERS:

STATION TYPE	NOVUS®	ODYSSEY	ENDEAVOR
Endeavor Duty Alert Station with LED Light Indicator			DTY-100
Odyssey Plus Duty Alert Station with LED Light Indicator		DTY-1000	
Novus® Duty Alert Station with LED Light Indicator	NV DTY-STEEL		

- For use with the West-Call® Novus®, Odyssey Plus and Endeavor Systems
- For a duty station with audio, order the staff/duty station STF-1000/D (Odyssey Plus), EV-STF 2/D (Endeavor) and STF-2000/D (Novus)

Novus® Duty Station

Operating Voltage	28 VDC
Power Consumption	1 watt maximum
Dimensions	4 ½"H x 2 ¾"W x 1 ½"D 4-inch square backbox with 1 gang plaster ring, Raco 190 with 768 one-gang adapter or equivalent. Minimum 2 1/8" depth required. Normal mounting is vertical. For remodel areas, use Raco #500 or 503 with #977 Grip-Lok's or equivalent. Minimum 2 ½" depth required.
Mounting	
Faceplate	Painted cold rolled steel
Faceplate Color	Standard color is Pantone 1C Warm Grey
Cable Requirement	CAT5 to associated Novus® Smart Dome when used with the Novus® system
Termination Requirement	Plug-on connector allows rapid mass termination. Mating connector is a Panduit CE156F22-10.

Endeavor Duty Station

Operating Voltage	24 VDC
Power Consumption	1 watt maximum
Dimensions	4 ½"H x 2 ¾"W x 1 ½"D 4-inch square backbox with 1 gang plaster ring, Raco 190 with 768 one-gang adapter or equivalent. Minimum 2 1/8" depth required. Normal mounting is vertical. For remodel areas, use Raco #500 or 503 with #977 Grip-Lok's or equivalent. Minimum 2 ½" depth required.
Mounting	
Faceplate	Painted cold rolled steel
Faceplate Color	Standard color is Pantone 1C Warm Grey
Cable Requirement	Use 4 conductor #22AWG cable Non-Shielded
Termination Requirement	2 wire splice

Odyssey Plus Duty Station

Operating Voltage	24 VDC
Power Consumption	1 watt maximum
Dimensions	4 ½"H x 2 ¾"W x 1 ½"D 4-inch square backbox with 1 gang plaster ring, Raco 190 with 768 one-gang adapter or equivalent. Minimum 2 1/8" depth required. Normal mounting is vertical. For remodel areas, use Raco #500 or 503 with #977 Grip-Lok's or equivalent. Minimum 2 ½" depth required.
Mounting	
Faceplate	Painted cold rolled steel
Faceplate Color	Standard color is Pantone 1C Warm Grey
Cable Requirement	Use 10 conductor #22AWG cable Non-Shielded
Termination Requirement	Plug-on connector allows rapid mass termination. Mating connector is a Panduit CE156F22-10.
Certifications	UL-1069 for US and Canada, E139082

NOTE: This information should not be used for final design. Consult West-Com for total system requirements. Specifications subject to change without notice.