



EV STF2

Staff Stations are used where voice communication is needed between the nurses' station and other non-patient occupied areas. Nurses' lounge, waiting rooms, locker rooms and break rooms are all examples of where staff stations are used. Staff stations are also available with a duty alert option.

- ▶ Inlaid membrane switch with call and monitor indicator LED and call buttons
- ▶ Duplex speech for uninterrupted communication between staff station and nurses' station
- ▶ Manual call origination by the call button
- ▶ Red nurse monitor/privacy LED
- ▶ Solid state circuitry throughout for long life and reliability
- ▶ Quick connect/disconnect pre-wired edge connector for simplified installation and service
- ▶ Large 2 3/4" Mylar cone speaker with a separate electret condenser microphone for natural full duplex communication
- ▶ Standard four-gang hospital grade ABS plastic faceplate (3 Gang box adapter ring is available)

VERSIONS AND MODEL NUMBERS:

STATION TYPE	ENDEAVOR	NO. OF PORTS USED
Standard Staff Station Includes a Call Button and a Cancel button	EV STF2	1
ADDITIONAL OPTIONS		
Standard Staff Station with a Duty buzzer	EV STF2/D	2
Standard Staff Station with Station Fault option	EV STF2/F	2
CUSTOM OPTIONS		
Standard Staff Station with a Staff Emergency button	EV STF2/E	2
Standard Staff Station with a Code button	EV STF2/C	2

- For use with the West-Call® Endeavor nurse call system
- To combine features, specify corresponding code letters
- Combining options may increase the number of ports used
- Station can mount over a 3 gang flush wall box. Specify ADP-3/4 for mounting ring. Station will semi-flush mount to wall, and extend approximately 1.1" away from the wall

Operating Voltage	26.5VDC +/-10%
Power Consumption	0.85W (standby); 6W (maximum with both dome lamps on)
Size	4 1/2"H x 8 1/4"W x 3 1/2"D
Mounting	4-gang backbox Raco #698. Normal mounting is Horizontal BOX MUST BE LEVEL
Faceplate	Hospital grade ABS UL94V-0 molded thermoplastic with inlaid membrane
Faceplate Color	Standard Warm Grey (Pantone 1C). Special colors supplied on individual basis
Membrane	.010 Lexan with hardcoat finish
Membrane Color	Background color, Pantone 4C Warm Grey, copy color Grey (Pantone 1C and 11C)
Termination	Plug-on connectors allowing rapid mass termination mating connectors - Panduit needed include one CE100F22-8 (home run), one CE100F22-3 (dome), one CE100F22-10 (audio), and up to two CE100F22-4 (priority and emergency external call devices)
Microphone	Cardiod Electret, sensitivity is -64db @ 1 microbar @ 1KHz
Speaker	2 3/4" Mylar cone with .5 ounce magnet. Minimum sensitivity is 90db SPL @ .25 watts @ 1ft.
Cable Requirements	6 conductor #22AWG (home run), 4 conductor #22AWG (station to dome, station to call device), 2 twisted shielded pairs #22AWG (audio)
Certifications	UL-1069 for US and Canada, E139082

NOTE: This information should not be used for final design. Consult West-Com for total system requirements. Specifications subject to change without notice.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com