

**LED Light View****LDL-1004****Back View**

The West-Call® LED Corridor Dome Light provides the required visual signal to notify staff members of a room's status. The Dome Light is equipped with four sections; the standard configuration is yellow, green, amber and red. The bottom LED can be specified as blue, turquoise or violet if required. The LED lights will virtually never burn out, as compared with an incandescent bulb. The Corridor Dome Light mounts on the wall or ceiling, which offers increased visibility from any reasonable angle and supports a wide variety of signals. Typical applications include corridor indication of patient calls, patient waiting, staff calls, emergency, code blue and code pink indications. The LED Dome Light is compatible with the West-Call® Odyssey Plus and West-Call® Endeavor systems only.

- ▶ Translucent wedge-shaped dome lens for maximum visibility in all directions, even at great distances and under high ambient lighting conditions
- ▶ Easy six pin .600 size panduit standard connection
- ▶ Oversized two-gang faceplate, hospital-grade ABS plastic
- ▶ Color is Pantone 1C Warm Grey
- ▶ Lens is made from unbreakable polystyrene UL94V0 plastic
- ▶ Normal and emergency calls distinguished by different visual signals for positive identification of call priority
- ▶ LED will virtually never burn out

VERSIONS AND MODEL NUMBERS:

STATION TYPE	MODEL NO.
LED Corridor Dome Light (Yellow, Green, Amber, Red)	LDL-1004
LED Corridor Dome Light (Yellow, Green, Amber, Blue)	LDL-1004/YGAB
LED Corridor Dome Light (Yellow, Green, Amber, Turquoise)	LDL-1004/YGAT
LED Corridor Dome Light (Yellow, Green, Amber, Violet)	LDL-1004/YGAV

- For use with the West-Call® Odyssey Plus and West-Call® Endeavor systems
- Custom configurations available with minimum order requirement only

Operating Voltage	28VDC
Power Consumption	<2 watts
Size	5 1/4"H x 5 1/4"W x 3 3/4"D
Mounting	4 11/16" square back box with two-gang plaster ring. Raco 257 with 818 or equivalent
Faceplate	Hospital grade ABS plastic back plate with attractive finish. Pantone 1C Warm Grey
Termination	Mating connectors are Panduit CE10022-6
Luminary	Molded white Polystyrene plastic, replaceable
LED colors	Yellow, Green, Amber, Red. Note: the bottom LED can be specified as Blue, Turquoise or Violet if required.
Certifications	UL-1069 for US and Canada, E139082

NOTE: This information should not be used for final design. Consult West-Com for total system requirements. Specifications subject to change without notice.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com