



**WALL INTERCOM
SL-1008**

The award winning design of the Marc II wall intercoms are wall mounted intercom stations with a four digit LCD display, four LED indicators, keypad with 10 ten digit keys and eight function keys, volume control, microphone and speaker. The LCD display indicates the number dialed, the number of the terminal that has left a call request, the number of your terminal, the number to which incoming calls are transferred, any messages that are stored in the station and the current time. The stations are designed for hands free communication between the user station and any other station in the system.

Features

- ▶ Hands Free Communications
- ▶ Duplex Audio
- ▶ Easy to read LCD Display
- ▶ Highly visible LED Indicators
- ▶ Easy to use Keypad
- ▶ Self Defining Function Keys
- ▶ Messaging between Stations
- ▶ Volume Control
- ▶ Four pin (telephone style) modular plug
- ▶ Built In Clock
- ▶ PCM Technology
- ▶ Overhead page capabilities
- ▶ Easily distinguishable Audio Signals
- ▶ Alarm Signaling Capabilities
- ▶ Recalling Capabilities
- ▶ Do Not Disturb Functions
- ▶ Call Transfer Capabilities
- ▶ Memory Capabilities
- ▶ Radio Paging Interface
- ▶ Telephone Interface
- ▶ Background Music Capabilities
- ▶ Door Open and Close Capabilities
- ▶ Video Camera Control Capabilities
- ▶ All Page Capabilities

Ordering Information

DESCRIPTION	MODEL NO.
Wall Station	SL-1008
Wall Station with Handset	SL 1008 H
Flush Mounting Wall Station with Wall Mounting Frame and Backbox	SL-1008 H-B
Surface Mounting Wall Station with Wall Mounting Frame and Backbox	SL-1008 H-P

- Stations are for use with either the West-Call® Marc II or the West-Call® Compac intercom systems.

Technical Specification

Dimensions	Height 11.81", Width 4.72", Depth 2.76"
Wiring	Each station uses its own 4 conductor, or 2 twisted pair cable 22 awg. The maximum length of the cable run is 3280 feet.
Color	Pantone Warm Gray 1C
Audio output power	600mW max
Power supply	40V (DC), supplied from the central processor



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
 2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com