



NV-DOME

The West-Call® NV-Dome provides clear visual notification to staff members of a room's status.

- Four segments;
- Long-life RGB LED lamps displaying yellow, green, orange, red, blue, violet and turquoise;
- Solid, Slow and Fast Flashing, and Scrolling indications;
- Mounts on the wall or ceiling, offering increased visibility from most angles.

Typical applications include corridor indication of patient calls, patient waiting, staff calls, emergency, code blue and code pink indications. The NV-Dome is compatible with the West-Call® Novus® system.

- ▶ Translucent lens sections which allow maximum visibility in all directions, from great distances and under high ambient lighting conditions.
- ▶ Easy connection to West-Com "Special Orange" cable via RJ-45 (data) and 3-pin panduit (power).
- ▶ Oversized two-gang faceplate, hospital-grade ABS plastic.
- ▶ Built-in buzzer for code calls.
- ▶ Optical contact closure input, configurable to any type of alarm.
- ▶ Normal and emergency calls distinguished by different visual signals for positive identification of call priority.
- ▶ Can be used as Zone Light.
- ▶ Long-life, low power RGB LED lamps.

VERSIONS AND MODEL NUMBERS:

STATION TYPE	MODEL NO.
Novus® Dome Light	NV-DOME

- * For use with the West-Call® Novus® system
- * Custom configurations available upon request for an additional cost

Operating Voltage	28VDC.
Power Consumption	<2 watts.
Size	5 1/4"H x 5 1/4"W x 3 3/4"D.
Mounting	4 11/16" square back box with two-gang plaster ring. Raco 257 with 818 or equivalent.
Faceplate	Hospital grade ABS plastic back plate with attractive finish. PSM 427 Light Grey Opaque.
Termination	Mating connectors are RJ-45 and Panduit CE156F22-3 (3 each, included)
Luminary	Molded white Polystyrene plastic, replaceable.
LED colors	Red, Green, Blue, Yellow, Orange, Violet, Turquoise- via program control
Certifications:	UL-1069 for US and Canada, E139082

NOTE: This information should not be used for final design. Consult West-Com for total system requirements. Specifications subject to change without notice.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
 2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com