

Introducing the West-Call® One-Gang Full-Duplex Audio Patient Station†.

The **NV-SPS1** is a single-gang device that features full-duplex audio and a remote speaker.

The West-Call® NV-SPS1 Features:

- ▶ Field Programmable Call Types: *Routine, Stat, Cord Out, Pain Med, Bed Pan, Bed Out, Bed Exit.*
- ▶ Full-Duplex Audio, Remote Speaker.
- ▶ Supports standard connections to Hill-Rom and/or Stryker® beds via the West-Call® NV-iBED, WC-BED and/or NV-BED.
- ▶ Field programmable assurance tones provide audio feedback to patients and staff that calls have been placed (*Routine, Stat, Cord Out, Pain Med, Bed Pan*).
- ▶ Privacy Lamp.
- ▶ Cord Out Override with call assurance tone.



- ▶ “Cleaning Mode” feature inhibits cleaning personnel from accidentally placing calls while readying a room.
- ▶ Single-Gang.
- ▶ Recommended use with NV-DOME/A.
- ▶ **Cable Requirements:**
CAT 5e (Data/Power); 2 pair shielded (Audio).
- ▶ **Optional (based on use:)**
4 conductor; 3-wire (TV); 12 conductor (bed interface).
- ▶ UL: Pending.
- ▶ Available: **NOW.**

Ordering Information:

Description	Model No.	Order No.
Novus® Single-Gang Patient Station with Call, Cancel and Staff Emergency	NV-SPS1	40135501

CONNECTION OPTIONS

Novus® LED Corridor Dome Light with Audio Connection	NV-DOME/A	40140013-A
LED Corridor Dome Light with Standard Colors	LDL-1004	30140035

- For use with the West-Call® Novus® System
- Custom LED colors for LDL-1004 are available at an additional cost

Please direct questions to West-Com's Technical Support Department at (707) 428-5900 ext. 5.

NOTE: This information should not be used for final design. Consult West-Com for total system requirements.

† West-Com Patented Innovations

Components of the West-Call® Novus® system are protected by one or more of the following U.S. Patents: 8,009,021, 7,994,900, D614,520

View West-Com's complete line of West-Call® health care communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.

2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • fax: 707-428-5941 • info@westcall.com

new product release