

#	ROOM / AREA	CALL TYPE	TIMER
1	Hold 2	Staff Emerg	00:09
2	Exam 2	Normal	01:04
3	Exam 7	Clean RM	00:42

SYSTEM MUTE ETH 10:53.22

NDT

The Novus® Display Terminal (NDT) is intended for hospital call centers where the centralized display of information is required.

- Displays calls and alerts received from the West-Call® product lines.
- Information remains on the screen until the event is cancelled at its source.
- Direct connection to TAP paging terminal is built in. Automated and manual text messages can be sent directly from the NDT.
- Unique colors, tones and messages can be assigned to each type of event.
- Alarms can be muted.

- ▶ Displays calls and alarms until cancelled at source
- ▶ Simple to operate
- ▶ Each type of alert may be assigned unique color and tone
- ▶ Central annunciation of Code Blue calls, component failures and many other programmable events
- ▶ 17" LCD Monitor
- ▶ Integrated computer
- ▶ Mini keyboard and Mouse

VERSIONS AND MODEL NUMBERS:

STATION TYPE	MODEL NO.
Novus® Display Terminal	NDT

- For use with the West-Call® Novus®, Odyssey and Endeavor systems

Processor	200 MHz x-86 Processor
Storage	2 GB Compact Flash
Display	Integrated 17" LCD
Input Power	100-240 VAC, 50-60 Hz (auto switch)
Monitor Dimensions	15.2" x 18.7" x 9" with stand 15.2" x 14.4" x 2.6" (without stand)
Operating Conditions	0°C ~ 40°C
Weight	Net with stand 11.1 lb. (5.0 kg) Net without stand 8.2 lb. (3.7 kg) Gross with stand 15.4 lb. (7.0 kg)

NOTE: This information should not be used for final design. Consult West-Com for total system requirements. Specifications subject to change without notice.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com