

Push Button Emergency Stations (Novus® and 2000-series)



ASSIST



STAFF CALL



EMERGENCY



CODE BLUE



STAFF EMERGENCY
CODE BLUE

See reverse for a complete list of standard available faceplates.

The Push Button Emergency Station is intended for use in patient rooms and other areas where priority calls require immediate attention. Color-coded tactile push buttons, a CANCEL button, and an LED call assurance indicator are standard features. Designed for use with the West-Call® Novus®, Odyssey and Endeavor systems.

- ▶ Large color-coded tactile buttons for placement of calls
- ▶ Highly visible call LED to assure that a call has been placed
- ▶ Large color-coded "CANCEL" button for termination of calls (except for combination units)
- ▶ Solid state circuitry
- ▶ Fire retardant high-impact hospital grade molded thermoplastic with inlaid membrane
- ▶ Relay output standard on Code stations
- ▶ Attractive Lexan membrane (Pantone 1C Warm Grey)
- ▶ Easy plug-in connection into the system wiring

VERSIONS AND MODEL NUMBERS:

| WORDING, (BUTTON / LED COLOR) | NOVUS® | NOVUS® VISUAL | HYBRID & ODYSSEY | ENDEAVOR |
|---|--------------|------------------|---------------------|----------------|
| HELP (RED) | NV-PBE | NVV-PBE | PBE-2000 | EV2K-PBE |
| STAFF EMERGENCY (RED) | NV-PBE/SE | NVV-PBE/SE | PBE-2000/SE | EV2K-PBE/SE |
| EMERGENCY (RED) | NV-PBE/E | NVV-PBE/E | PBS-2000/E | EV2K-PBE/E |
| CODE BLUE (BLUE) | NV-PBE/CB | NVV-PBE/CB | PBE-2000/CB | EV2K-PBE/CB |
| CODE (BLUE) | NV-PBE/C | NVV-PBE/C | PBE-2000/C | EV2K-PBE/C |
| CODE PINK (PINK) | NV-PBE/CP | NVV-PBE/CP | PBE-2000/CP | EV2K-PBE/CP |
| ASSIST (YELLOW) | NV-PBE/A | NVV-PBE/A | PBE-2000/A | EV2K-PBE/A |
| STAFF CALL (WHITE) | NV-PBE/SC | NVV-PBE/SC | PBE-2000/SC | EV2K-PBE/SC |
| STAFF EMERGENCY (RED) AND CODE BLUE (BLUE) | NV-PBE/SE/CB | NVV-PBE/SE/CB | PBE-2000/SE/CB | EV2K-PBE/SE/CB |
| EMERGENCY STATION CLEAR PROTECTOR | ESP-2000 | | | |
| EMERGENCY STATION CLEAR PROTECTOR (DUAL) | ESP-2000/D | | | |

- For use with the West-Call® Novus®, Odyssey and Endeavor systems
- Custom color and wording of faceplates available upon request, minimum order and/or setup charges apply

| | |
|-------------------------|--|
| Operating Voltage | 28 VDC |
| Power Consumption | 1 watt maximum |
| Dimensions | 4 ½" H x 2 ¾" W x 1 ½" D |
| Mounting | 4-inch square backbox with one-gang plaster ring, Raco 190 with 768 one-gang adapter or equivalent. Minimum 2 1/8" depth required. Normal mounting is vertical. For remodel areas, use Raco 500 or 503 with 977 Grip-Lok or equivalent. Minimum 2 ½" depth is required |
| Faceplate | Hospital grade UL94V-0 ABS molded thermoplastic with inlaid membrane |
| Faceplate Color | PMS 427; Light Grey Opaque |
| Lamp Life | 500,000 hour minimum |
| Switch Life | 100,000 cycles minimum |
| Cable Requirement | Novus®: CAT-5; Odyssey and Endeavor: 4 conductor 22AWG |
| Termination Requirement | Plug-in connector allows rapid mass termination. Novus®: RJ-45; Odyssey and Endeavor: Panduit CE100F22-8 |
| Certifications | UL-1069 for US and Canada, E139082 |

NOTE: This information should not be used for final design. Consult West-Com for total system requirements. Specifications subject to change without notice.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com