



Novus® FHR Module

The West-Call® Novus® Field Home Run (FHR) Module is designed to be a remote field homerun controller. The FHR Module is responsible for the communication between the dome light network and the master stations.

Features

- ▶ Minimum Mounting Area Required
- ▶ 16 Dome Lights per FHR
- ▶ Unlimited Networking Limitations
- ▶ Solid State Circuitry
- ▶ Voltage Test Points
- ▶ LED Status Indicators

Ordering Information

Description	Model Number	Part Number
Field Home Run Module. Remote panel supports 16 Dome Lights. Includes required electronics, PS-28 and 12-12 Hoffman Box.	FHR Module	40136014

Technical Specification

Operating Voltage 120 VAC and 28 VDC +/-10%

Power Consumption 41.25 watts

Weight 15 pounds

Mounting Cabinet 12"H x 12"W x 8"D

Termination CE100F22-5 Panduit connectors for field audio connections and CE156F22-3 for power connections. RJ-45 plugs for homerun data cables, master network cables, CNTR-1 network connections.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
 2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com