



**EMERGENCY
PULL CORD**



**SLAVE PULL
CORD**

Emergency Pull Cord Stations alert staff members of the location where prompt emergency help is required. An eight foot pull cord with a tassel extends from the station to the ground, allowing for easy access by patients or staff, whether in a chair or from the floor. The stations feature a highly visible call assurance LED to let patients know their calls went through and that providers are on the way. Each Pull Cord Station is equipped with a large “CANCEL” Sealed Membrane Active Raised Tactile or SMART™ switch for easy call cancellation. And a special infection-control-approved, glow-in-the-dark pull cord is available to enhance patients’ sense of security. The Pull Cord Stations are for use with the West-Call® Novus®, Odyssey and Endeavor systems.

- ▶ Highly visible call assurance LED lets patients know their calls have been placed
- ▶ Large "CANCEL" SMART™ switch for easy call cancellation
- ▶ Fire retardant high impact hospital grade molded thermoplastic with inlaid membrane
- ▶ Polyurethane, Glow-in-the-dark and Nylon cords available
- ▶ Attractive Lexan membrane
- ▶ Solid state circuitry
- ▶ Easy plug-in connection into the system wiring
- ▶ Eight foot pull cord with a tassel for ease of gripping

VERSIONS AND MODEL NUMBERS:

STATION TYPE	NOVUS®	NOVUS® VISUAL	HYBRID & ODYSSEY	ENDEAVOR*
Emergency Pull Cord Station	NV-EPC	NVV-EPC	EPC-2000	EPC-2000
Emergency Pull Cord Station with Waterproof Gasket	NV-WPC	NVV-WPC	WPC-2000	WPC-2000
Slave Pull Cord Station with Waterproof Gasket (used with an EPC station)	SWPC-2000	SWPC-2000	SWPC-2000	SWPC-2000

MODEL NUMBER SUFFIX:

- none* Nylon Cord
- /P Polyurethane Cord
- /G Glow-in-the-dark Polyurethane Cord

- * Programmed for the Endeavor system. Specify –EV at the end of the part number (i.e., 40139041-EV for EPC-2000)
- For use with the West-Call® Novus®, Odyssey and Endeavor systems

Operating Voltage	24-28 VDC
Power Consumption	1 watt maximum
Dimensions	4 ½" H x 2 ¾" W x 1 ½" D
Mounting	4-inch square backbox with one-gang plaster ring, Raco 190 with 768 one-gang adapter or equivalent. Minimum 2 ⅛" depth required. Normal mounting is vertical. For remodel areas, use Raco 500 or 503 with 977 Grip-Lok or equivalent. Minimum 2 ½" depth is required.
Faceplate	Hospital grade UL94V-0 ABS molded thermoplastic with inlaid membrane
Faceplate Color	PMS 427; Light Grey Opaque
Lamp Life	500,000 hour minimum
Switch Life	100,000 cycles minimum
Cable Requirement	Novus®: Cat5e; Odyssey, Hybrid and Endeavor: 4 conductor 22AWG
EPC to SWPC Cable	4 conductor 22AWG
Termination Requirement	Plug-in connector allows rapid mass termination. Novus®: RJ-45; Odyssey, Hybrid and Endeavor: Panduit CE156F22-8
Certifications	UL-1069 for US and Canada, E139082

NOTE: This information should not be used for final design. Consult West-Com for total system requirements. Specifications subject to change without notice.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com