



NCM-815T

The West-Call® Odyssey Plus Master Station comes complete with an IPC-3 Computer, 15" flat panel touch screen display with integrated phone, 84 key keyboard, mouse, phone, JMA, and Windows® XP Embedded operating system. The interactive touch screen interface uses a floor map displaying all rooms assigned to the nursing unit. Large descriptive buttons with colorful animated graphics make finding and using functions simple. Help buttons located throughout the Odyssey Plus program allow the user to obtain answers to operational questions on demand. Full duplex voice communication is available from the master station to patient stations, staff stations, staff duty stations, and other master stations. Other features include fully integrated radio paging, staffing reports, staff assignment, and patient information, all customizable to meet the nursing unit's needs.

- ▶ Full Duplex Audio
- ▶ Integrated Radio Paging
- ▶ Color 15" Flat Panel Touch Screen Display
- ▶ Online Help Menus
- ▶ Interactive Room Map Display
- ▶ Staff Reports
- ▶ Master to Master Communication
- ▶ Staff Assignments
- ▶ Patient Information
- ▶ Customizable Features

VERSIONS AND MODEL NUMBERS:

STATION TYPE	NOVUS®
West-Call® Odyssey Plus Nurse Call Master. Includes: IPC-3 Computer, 15" flat panel touch screen display with integrated phone, 84 key keyboard, mouse, JMA, Windows® XP Embedded operating system	NCM-815T

OPTIONS	
TQI Reporting. Add this option to each master computer where TQI reports are needed. This option requires use of a TQI Server and Client.	/TQI

- For use with the West-Call® Odyssey system

MONITOR

Display Size	15" Diagonal
Power Consumption	30W
Resolution	1024 x 768 at 60, 70 or 75 Hz
Response Time	25 msec (typical)
Brightness	300 cd/m ²
Dimensions	Width: 13.99", Height: 11.27", Depth: 10.44"
Weight	Actual: 25 lb Shipping: 38 lb
Touch Screen	AccuTouch Five-Wire Resistive

COMPUTER

Power Supply	12 VDC External DC Power Adapter
Motherboard	Integrated Intel 855GME
Processor	Low Voltage 1.4GHz Intel Pentium M
Memory	512 MB RAM
Video Card	Intel 855GME utilizing Integrated Intel Extreme Graphics 2 technology
Connectivity	Two 9-Pin D-Sub Serial Port, One RJ-45 Network Connector, PS/2 Mouse/Keyboard Port, 15-Pin VGA, 3 USB on back, 1 USB on front
Hard Drive	2GB Solid-State Flash
Voltage	12 VDC – 24 VDC, 12 VDC @ 3A, 24 VDC @ 1.5A
Weight	5 lbs.

OTHER

Phone	Integrated with Monitor
Keyboard	84 Keys
Cabling	Category 5 Cable From Master Computer To HUB. West-Call® Special Black Cable From Master Phone to Distribution Panel.
Certifications	UL-1069 for US and Canada, E139082

NOTE: This information should not be used for final design. Consult West-Com for total system requirements. Specifications subject to change without notice.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems, Inc.
2200 Cordelia Road • Fairfield, CA 94534 • 800-761-1180 • info@westcall.com