

**DTY-1000**

The Duty station is an audible alert device commonly used in staff lounge areas where staff members can be alerted to system calls. It is capable of producing multiple tones to differentiate call types.

## Features

- ▶ Reports 3 levels of calls with audible buzzer
- ▶ Fire retardant painted cold rolled steel
- ▶ Solid state circuitry
- ▶ Plug-in connection to system wiring
- ▶ Color is a warm gray (Pantone 1C)

## Ordering Information

DESCRIPTION	MODEL NO.
Duty Alert Station with LED Light Indicator	DTY-1000

- For use with the West-Call® Odyssey Plus
- For a duty station with audio, order the staff/duty station STF-1000/D

## Technical Specification

Operating Voltage	28 VDC
Power Consumption	1 watt maximum
Dimensions	4 1/2"H x 2 3/4"W x 1 1/2"D
Mounting	4-inch square backbox with 1 gang plaster ring, Raco 190 with 768 one-gang adapter or equivalent. Minimum 2 1/8" depth required. Normal mounting is vertical. For remodel areas, use Raco #500 or 503 with #977 Grip-Lok's or equivalent. Minimum 2 1/2" depth required
Faceplate	Painted cold rolled steel
Faceplate Color	Standard color is Pantone 1C Warm Grey
Cable Requirement	Use 10 conductor #22AWG cable
Termination Requirement	Plug-on connector allows rapid mass termination. Mating connector is a Panduit CE156F22-10



View West-Com's complete West-Call® line of healthcare communications solutions at [www.westcall.com](http://www.westcall.com)

West-Com Nurse Call Systems Incorporated  
 P.O. Box 640 • Danville, CA 94526 • 800-761-1180 • fax: 925-831-0842 • [info@westcall.com](mailto:info@westcall.com)