



NCM-815T

The Odyssey Plus Master Station comes complete with a 15" touch screen flat panel display, computer, keyboard, mouse, and a phone. The interactive touch screen interface uses a floor map displaying all rooms assigned to the nursing unit. Large descriptive buttons with colorful animated graphics make finding and using functions simple. Help buttons located throughout the Odyssey Plus program allows the user to obtain answers to operational questions on demand. Full duplex voice communication is available from the master station to patient stations, staff stations, staff duty stations, and other master stations. Other features include fully integrated radio paging, staffing reports, staff assignment, and patient information, all customizable to meet the nursing unit's needs.

- ▶ Full Duplex Speech
- ▶ Integrated Radio Paging
- ▶ Color 15" Touch Screen Flat Panel Display
- ▶ Online Help Menus
- ▶ Interactive Room Map Display
- ▶ Staff Reports
- ▶ Master to Master Communication
- ▶ Staff Assignments
- ▶ Patient Information
- ▶ Customizable Features

DESCRIPTION	MODEL NO.
Odyssey Plus Master Station with 15" Touch Screen LCD, Phone, Keyboard, Mouse, and Computer	NCM-815T

OPTIONS	
TQI for call reporting Feature	/TQI
Battery Back Up and Surge Protection	UPS-8500

- To combine features, specify corresponding code letters that begin with a (/) to the end of the model number (e.g. NCM-815/TQI).

MONITOR

Display Size	15" Diagonal
Power Consumption	30W
Resolution	1024 x 768 at 60, 70 or 74 Hz
Response Time	30ms
Brightness	300 cd/m ²
Dimensions (with base)	Width: 15.4", Height (Inc. Base): 15.4", Depth (Inc Base): 8.2"
Weight	Actual: 15.2 lb (6.9 kg) Shipping: 21.6 lb (9.8 kg)
Touch Screen	AccuTouch Five-Wire Resistive

COMPUTER

Power Supply	External DC Power Adapter
Motherboard	All-In-One Board
Processor	1.8GHz Intel processor, 128K Cache
Memory	128 MB SDRAM
Video Card	Integrated. Intel Extreme Graphics
Connectivity	One 9-Pin D-Sub Serial Port, One 25-Pin D-Sub Parallel Port, One RJ-45 Network Connector, PS/2 Mouse & Keyboard Port, 15-Pin VGA Port, 4 USB on back 2 USB on front
Hard Drive	20GB, EIDE, 9.5 MM, 5400 RPM
CD-ROM Drive	Removable CD-ROM Drive
Voltage	90-135 V at 60 Hz; 180-265 V at 50 Hz
Floppy Disk Drive	Optional
Weight	7.2 lbs.

OTHER

Phone	DC 12V
Keyboard	84 Keys
Cabling	Category 5 Cable From Master Computer To HUB. West-Call® Special Black Cable From Master Phone to Central.



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems Incorporated
P.O. Box 640 • Danville, CA 94526 • 800-761-1180 • fax: 925-831-0842 • info@westcall.com