



PSM-1003

The West-Call® Power Supply Modules provide low voltage, current limited power to all signaling units for the West-Call® Odyssey Plus. Each assembly provides independent replaceable power supplies and a 120VAC power outlet to facilitate plug-in type power connections. All Power Supply Modules include high frequency switching, solid state circuitry, electronic circuit breaker overload protection and a power LED. A UPS is added to protect against power fluctuations and power outages. Operating Voltage: 120 VAC, 60HZ.

- ▶ High Frequency Switching
- ▶ Power Cable Assembly
- ▶ Header Connection Strip for Ease of Wiring
- ▶ Solid State Circuitry
- ▶ Optional UPS to Protect Against Power
- ▶ Aluminum Back Panel for Ease of Installation
- ▶ Electronic and Circuit Breaker Overload Protection
- ▶ Fluctuations and Power Outages

DESCRIPTION	MODEL NO.	TERMINAL CAN
Power supply module that includes one (1) 28 volt 3.5 amps power supply	PSM-1001	1822/6
Power supply module that includes two (2) 28 volt 3.5 amps power supplies	PSM-1002	1822/6
Power supply module that includes three (3) 28 volt 3.5 amps power supplies	PSM-1003	1822/6
Power supply module that includes four (4) 28 volt 3.5 amps power supplies	PSM-1004	1822/6
Power supply module that includes five (5) 28 volt 3.5 amps power supplies	PSM-1005	1822/6
Power supply module that includes six (6) 28 volt 3.5 amps power supplies	PSM-1006	3624/6
Power supply module that includes seven (7) 28 volt 3.5 amps power supplies	PSM-1007	3624/6

- For PSM-1001 TO 1005 flush mounted enclosure order with door, order part numbers TC-1822/6 and TCD-1822 F
- For PSM-1006 flush mounted enclosure order with door, order part numbers TC-3624/6
- For surface mounted enclosure with door, order part numbers TC-1822/6 and TCD-1822/S
- For UPS option specify /B at the end of the part number (i.e., PSM-1002/B)
- Recommended load per Power Supply is 12 patient rooms

Power Consumption	120 watts per supply
Size	17" H x 20-1/8"W x 3.5"D (PSM-1001 to PSM-1005); 32" H x 20"W x 3.5"D (PSM-1006)
Mounting Cabinet	21-9/16 H x 18-5/16 W x 4-1/16 D, Electrical enclosure or equivalent Flush or surface mount available (PSM-1001 to PSM-1005) 36"H x 24"W x 6"D, electrical enclosure or equivalent. Flush or surface mount available (PSM-1006)
Regulation	Fold back current limiting with restart
Cable Requirement	2 conductor #18AWG per power supply to associated central control terminal
UPS Power	120VAC, 60HZ



View West-Com's complete West-Call® line of healthcare communications solutions at www.westcall.com

West-Com Nurse Call Systems Incorporated
P.O. Box 640 • Danville, CA 94526 • 800-761-1180 • fax: 925-831-0842 • info@westcall.com