



**SLAVE PULL  
CORD**



**EMERGENCY  
PULL CORD**

Emergency Pull Cord Stations alert staff members of the location where prompt emergency help is required. Pulling on a cord that goes from the station to the ground places an emergency call. This allows patients who may have fallen to place a call while lying on the floor. It is for use with the West-Call® Odyssey Plus and West-Call® Endeavor systems.

- ▶ Large color-coded emergency label for placement of calls
- ▶ Highly visible call LED to assure that a call has been placed
- ▶ Large color-coded "CANCEL" or "CANCEL AT TOILET" label for cancellation of calls
- ▶ Fire retardant high impact hospital grade molded thermoplastic with inlaid membrane
- ▶ Attractive Lexan membrane (Pantone 1C Warm Grey)
- ▶ Solid state circuitry
- ▶ Easy plug-in connection into the system wiring
- ▶ Eight foot pull cord with a tassel on the end for ease of gripping

STATION TYPE	ODYSSEY PLUS MODEL NO.	ENDEAVOR MODEL NO.
Emergency Pull Cord Station	EPC-1000	EV EPC
Emergency Pull Cord Station with Water Resistant Gasket	WPC-1000	EV WPC
Slave Pull Cord Station (used with an EPC, or PBE station)	SPC-1000	EV SPC
Slave Pull Cord Station with Water Resistant Gasket (used with an EPC, or PBE station)	SWPC-1000	EV SWPC

- Custom color faceplate available upon request
- Custom color membrane available upon request
- Custom membrane wording available upon request
- For use with the West-Call® Odyssey Plus and West-Call Endeavor

Operating Voltage	12-30 VDC; 12-18 VAC
Power Consumption	1 watt maximum
Dimensions	4 1/2"H x 2 3/4"W x 1 1/2"D
Mounting	4-inch square backbox with one-gang plaster ring, Raco 190 with 768 one-gang adapter or equivalent. Minimum 2 1/8" depth required. Normal mounting is vertical. For remodel areas, use Raco #500 or 503 with #977 Grip-Lok's or equivalent. Minimum 2 1/2" depth required
Faceplate	Hospital grade UL94V-0 ABS molded thermoplastic with inlaid membrane
Faceplate Color	Standard color is Pantone 1C Warm Grey
Membrane	.010 Lexan with hardcoat finish background color Pantone 4C Warm Grey. Cancel color Pantone 1C and 11C Warm Grey
Lamp Life	500,000 hour minimum
Switch Life	100,000 cycles minimum
Cable Requirement for the EPC and WPC	Use 4 conductor #22AWG cable to associated patient station or SDL-8000. Use 6 conductor #22AWG cable to associated Closure Plus Modules or I/O board
Cable Requirement for the SPC and SWPC	Use 4 conductor #22AWG cable to associated EPC or PBE
Termination Requirement	Plug-in connector allows rapid mass termination. Mating connector is a Panduit CE156F22-10



View West-Com's complete West-Call® line of healthcare communications solutions at [www.westcall.com](http://www.westcall.com)

West-Com Nurse Call Systems Incorporated  
P.O. Box 640 • Danville, CA 94526 • 800-761-1180 • fax: 925-831-0842 • [info@westcall.com](mailto:info@westcall.com)